


This page lists the contents included in the box. Please take time to identify the hardware as well as the individual components of the product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Please follow the assembly instructions closely. Improper assembly can result in personal or property damage.

**Note: 2 adults are required to safely install this product.**



**WARNING:**  
**CHOKING HAZARD**  
Small parts. Not for children under 3 yrs.



x 01



x 01



NOT INCLUDED




NOT INCLUDED

For safe mounting, it is essential to use a wall anchor appropriate to your wall type (i.e. plaster, drywall, concrete, etc.). **The following instructions are for drywall installation only.** Mount to wood joists whenever possible.

**If you are unsure about your ceiling type or what mounting method you should use, consult a qualified professional or your local hardware store.**

- A. Determine position for the canopy, noting the diameter of the canopy and that the canopy should hang to the desired length. This canopy should accommodate 8-9 foot ceilings.
- B. Drill a pilot hole slightly smaller in diameter than the plastic anchor. If mounting to wood joists do not use the plastic anchor. Insert anchor into hole and gently tap until flush with the ceiling.
- C. Fasten the eyelet screw into the plastic anchor until the threads are no longer visible. **Do not overtighten.**



**1**

**2**

At the top of the canopy there are two ties. Feed one of these ties through the eye of the eyelet screw and tie it to the other tie, securing the two ends together with a double knot. Adjusting the placement of the knot will change the height of the canopy.

Installation is now complete.

