


 **WARNING**

**ADULT ASSEMBLY REQUIRED**

**FALL HAZARD** – To prevent death or serious injury from falls, always keep child within arm's reach.


**NEVER LEAVE CHILD UNATTENDED**

- This changing table / tray are designed to be used only with Land of Nod changing pad provided. The dimensions of that pad are 34-1/2" X 16-1/2"
- Changing tray is designed to attach to Land of Nod Dresser. If attaching to any other surface the minimum dimensions needed are 36" X 17 3/4". The surface must be level, stable and structurally sound.
- This product is not intended to be used as a changing table without pad.
- Use of this product without changing pad may result in death or serious injury to your child from falling.
- Follow all instructions on attaching and using changing tray and pad.
- Please follow restraint system instructions provided with changing pad.
- Read all instructions before using.
- Keep instructions for future use.
- Do not use changing table if tray or pad is damaged or broken
- The Land of Nod does not recommend using changing tray for children over 30 Lbs.



Thank you for purchasing the **Changing Tray**. This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

### HARDWARE



2 - mounting plates




8 - screws



Missing hardware? Please call **800.933.9904** for replacements.  
NOTE: Contains small parts. Keep away from small children.

### TOOLS REQUIRED

Phillips head screwdriver



(We recommend the use of hand tools instead of power tools)



NOTE: Make sure to secure mounting plates to pilot holes. Do not over tighten the screws.

# 1

Determine the desired orientation for **changing tray** and place onto **Land of Nod dresser** (sold separately) as shown. Attach **2 mounting plates** to backs of tray/dresser as shown. Secure each plate with 4 screws with a **Phillips head screwdriver**. Assembly is now complete.

### CLEANING AND CARE

Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Do not use furniture wax or polish as the unit is finished with a protective clear lacquer.